


Assembly instructions

Solo / Big / Super Niedervolt

Light source: Halostar ECO (Osram), Socket: GY6.35

The lamp has been designed and built in accordance with applicable harmonised standards and other technical specifications. It is therefore state-of-the-art and ensures safe operation. The lamp may only be used for the intended purpose.

Front and top view



Note:

Position the lamp at eye level or just slightly higher. This prevents being dazzled by the light. The safety distance from the ceiling and from, e.g. a table below the lamp, must be a minimum of 0.5 m.


ATTENTION!

The connection cable must be isolated from the mains before assembly.

Assembly:

It is recommended that assembly is implemented by a specialist company. We ask for your understanding that we can only offer a guarantee if assembly is implemented correctly.


- ① Attach the bracket with dowels and screws to the ceiling.
- ②Determine the required pendant length and shorten the wires and the cable. The cable and the wires should be left approx. 15cm longer.
- ③Pass the wire through the panel holder so that the ball is engaged.
- @Connect the earth conductor (yellow/green) to the earthing lead on the
- (5) Connect the supply cable to the primary side of the transformer. Then guide the lamp cable through the canopy and connect it to the secondary side of the transformer.
- © Push the canopy over the bracket and fasten the canopy with the two canopy
- Push the 3 wires through the wire holder. To align the light, push/pull the individual wires in/out of the wire holder until positioned as required (see
- ® Lock the cable in place with the strain relief.
- (9) Insert the lens and bulb.



Bulb Installation:

- ① Insert the lens (with the curve facing downwards) in the lamp head.
- 2 Press the bulb with both pins into the two holes of the socket. Do not touch the glass bulb itself during insertion.
- ③ Place the glass panel with the printed side upwards on the inner edge of the lens housing and insert the snap ring in the groove.

Wire holder principle



Dimming:

The lamp can be dimmed with a trailing edge-phase dimmer. The total Watt value of all luminaires must not exceed the maximum Watt value of the dimmer.

We recommend cleaning the lamp with a soft, dry cloth. A commercial glass cleaner can be used to clean the lens.



Licht im Raum Telefon Dinnebier GmbH Telefax Graf-Adolf-Straße 49 www.Licht-im-Raum.de 40210 Düsseldorf info@Licht-im-Raum.de

02 11/9 94 00-0 02 11/9 94 00-60

